# Ordering System Room Item Manager Module Help

## CONTACT SUPPORT:

| | |
|---|---|
| **COMPANY NAME:** | Ultimate Control |
| **SUPPORT CONTACT:** | Mohamed Sadek |
| **EMAIL ADDRESS:** | support@ultcontrol.com |

## GENERAL INFORMATION

| | |
|---|---|
| **SIMPLWINDOWS NAME:** | Ordering System Room Item Manager V1.0 |
| **CATEGORY:** | Miscellaneous |
| **VERSION:** | 1.0 |
| **SUMMARY:** | Search for room in room list and read room information from the list, search can be done using the room ID only |
| **CRESTRON HARDWARE REQUIRED:** | 3-series & 4-series processors **only** |
| **SETUP OF CRESTRON HARDWARE:** | N/A |
| **CABLE DIAGRAM:** | N/A |

## NOTES:

| | |
|---|---|
| **General Notes:** | • If room ID is not found in the room list, feedback channels will be empty as indication that item is not found<br>• Room data read in the module is static data, which means that these data are updated globally in the program to make available for other modules like the **Ordering System Room Item Manager** Module. Only 1 instance of this module should be added to single program, if more than instance is used with different menu data files, read data will follow the last read file |

## CONTROL:

| | | |
|---|---|---|
| **search_room_id** | S | Use to set the ID of the room to be read from list |

## FEEDBACK:

| | | |
|---|---|---|
| **target_room_id** | S | Displays the ID of the room read from list, will be empty string if room is not found |
| **target_room_name** | S | Displays the Name of the room read from list, will be empty string if room is not found |

## TESTING:

| | |
|---|---|
| **OPS USED FOR TESTING:** | 3-Series: v1.601.3934.21185 |
| **SIMPL WINDOWS USED FOR TESTING:** | 4.14.20 |
| **DEVICE DB USED FOR TESTING:** | 200.01.001.00 |
| **CRES DB USED FOR TESTING:** | 200.00.004.00 |
| **SYMBOL LIBRARY USED FOR TESTING:** | 1113 |
| **SAMPLE PROGRAM:** | Ordering System V1.0 Demo DIN-AP3 |
| **REVISION HISTORY:** | V1.0 Initial Release |